

C29SSMAX



USE: use only on a Cross-country or Cross Mountain MTB fitted with disc brakes. Any other use (such as on a tandem, road bike, cyclo-cross bike, free-ride or downhill bike...) is highly inadvisable, is the sole responsibility of the user and voids the Mavic warranty.
Recommended maximum weight of the cyclist and equipment: 100 kg

WHEEL WEIGHTS WITHOUT QUICK-RELEASE SKEWER

Front: 815 g
Rear: 935 g

WHEEL REFERENCES INTERNATIONAL STANDARD

Front: 995 886 10
Rear: 995 857 13
Pair: 995 858 14

RIMS	SALES REFERENCES
	<p>Front: 996 063 10 Rear: 995 063 13</p> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Ø VALVE HOLE Ø: 8.5 mm with 6.5 mm valve adaptor Length: ≥ 32 mm</p> </div> <div style="width: 45%;"> <p>RECOMMENDED TIRE WIDTH Dimensions: Ø 29" ETRTO 622 x 19C compatible and Tubeless UST Recommended tire width: 1.5 to 2.3</p> </div> </div>

HUBS	MAINTENANCE: Clean with a dry cloth or soapy water if necessary. Do not use a high-pressure washer.

WHEEL BUILDING	REFERENCES AND LENGTHS:
	<p>Front: 996 066 01, length 292 mm (per 13, integrated nipples) Rear drive side: 996 067 01, length 279 mm (per 12, integrated nipples) Rear non-drive side: 996 068 01, length 293.5 mm (per 12, integrated nipples)</p>
<p>FEATURES: Black round, straight pull Zicral spokes (with one decorated per wheel) with integrated, self-locking M7 aluminum spoke nipples</p>	<p>LACING PATTERN: Front: 2-cross lacing on both sides Rear: Isopulse</p>
	<p>TENSION: Front disc side: 110 to 130 kg Rear drive side: 120 to 140 kg</p>

ACCESSORIES	WHEELS SUPPLIED WITH:	MAINTENANCE
<ul style="list-style-type: none"> • BX 601 front quick-release M40140 • BX 601 rear quick-release M40141 • Computer magnet M40540 • M7 spoke wrench M40494 (with rear wheel) • UST valves 995 282 01 • Anti-ejection plugs 996 065 01 (with rear wheel) • Free play bearing adjustment wrench M40123 (with rear wheel) • User guide and warranty card 		<p>Front hub assembly diameter conversion See 2009 TM, page 25 Replacing the front axle and bearings See 2009 TM, page 26 Replacing the rear axle See 2007 TM, page 20 Maintaining and replacing the free wheel mechanism See 2007 TM, page 21 Replacing the rear bearings See 2003 TM, page 22 Replacing a spoke See 2003 TM, page 24 Replacing the front rim See 2007 TM, page 22 Replacing the rear rim See 2006 TM, page 17</p>
Refer to the website for quick and convenient access to information: www.tech-mavic.com		