

1.2. FRONT BEARING AND AXLE KIT ON THE CROSSMAX™ SL DISC AND CROSSMAX™ XL WHEELS

Tools needed:

- 1 x 5 mm Allen wrench
- 1 x 10 mm Allen wrench
- 1 hub wrench M40123
- Bearing pullers M40119

- 1** Loosen the free play adjustment nut one turn using the hub wrench M40123 by holding the other end of the axle with a 5 mm Allen wrench, to avoid damaging the bearings when mounting the axle again.
- 2** Remove the fork support on the adjustment nut side. This is press fit on the end of the axle.
- 3** Insert a 5 mm Allen wrench on the opposite side of the adjustment nut and the 10 mm Allen wrench on the adjustment nut side.
- 4** Loosen the axle end screw.
- 5** Remove the axle.
- 6** Drive out the bearings with the bearing pullers M40119 (long rod, see page 40) ;
- 7** Mount the new bearings using the bearing pullers M40119 ;
- 8** Replace the axle and mount it again using both the 5 and 10 mm Allen wrenches (torque: 6 - 8 Nm) ;
- 9** Clip the fork support back on.
- 10** Put the wheel back in place on the fork, tighten the quick release skewer, and adjust the bearing free play using the hub wrench M40123.

