

REPLACING STICKERS ON COSMIC CARBON (SL/SR/SLR/80/ULTIMATE)



Remove the original "Cosmic" stickers by pulling them up very gently to prevent leaving adhesive residue on the surface of the rim.



Leave the small sticker with the Mavic logo in place: it will be used as a guide during placement of the new sticker; furthermore, it is not included in your new sticker kit.



Clean the sides of the rim with the cleaning wipe supplied in the sticker kit.



First stick the "Cos" part, placing the right angle of the upper left-hand part of the letter C on the right end of the small sticker featuring the Mavic logo. A constant minimum space of 13 mm must be observed between the top of the sticker and the top of the rim.



Next, place the 2nd "mic" part aligned with the "Cos" part. A constant space of 13 mm must be observed between the top of the sticker and the top of the rim.