

# CROSSRIDE UB/DISC 11



**Use:** use only on a Cross-country or Cross-mountain MTB fitted with disc brakes. Any other use (such as on a tandem, road bike, cyclo-cross bike, free-ride or downhill bike...) is highly inadvisable, is the sole responsibility of the user and voids the Mavic warranty.  
Recommended maximum weight of the cyclist and equipment: 100 kg.

## WHEEL WEIGHT WITHOUT QUICK-RELEASE SKEWER

Front: 900 g  
Rear: 1040 g

## WHEEL REFERENCES

Front: 117 786 10  
Rear: 117 787 13  
Pair: 117 788 14

| RIMS | SALES REFERENCES: Front and rear: 120 217 15   |  |
|------|--|--|
|      | <p><b>Ø VALVE HOLE</b><br/>Ø: 8.5 mm with 6.5 mm valve adapter<br/>Length: ≥ 32 mm</p> | <p><b>RECOMMENDED TIRE WIDTH AND PRESSURE</b><br/>Dimensions:<br/>Ø 26"<br/>ETRTO 559 x 19C<br/>Recommended tire width: 1.5 to 2.3</p> |
|      |  |  |

| HUBS | MAINTENANCE: Clean with a dry cloth or soapy water if necessary. Do not use a high-pressure washer. |
|------|---|
|      |   |

|  |  |
|--|--|
|  |  |
|--|--|

| WHEEL BUILDING   | REFERENCES AND LENGTHS: Front and rear: 996 892 01, length 261 mm (per 12, with nipples) |
|--|--|
| <p><b>FEATURES:</b><br/>Silver stainless steel straight pull spokes with Self-Lock system and conventional spoke nipples</p> | <p><b>LACING PATTERN:</b><br/>Front and rear: 2-cross lacing on both sides</p>           |
| <p><b>TENSION:</b><br/>Front disc side: 100 to 120 kg<br/>Rear drive side: 120 to 140 kg</p>                                 |  |

| ACCESSORIES  | WHEELS SUPPLIED WITH: | MAINTENANCE   |
|--|-----------------------|---|
| <ul style="list-style-type: none"> <li>• BR 101 front quick release: M40350</li> <li>• BR 101 rear quick release: M40351</li> <li>• Rim tape 559x20x0.6</li> <li>• Wheel user guide</li> </ul> |                       | <p>Replacing the front axle and bearings See 2004 TM, page 19</p> <p>Replacing the rear axle See 2004 TM, page 20</p> <p>Maintaining and replacing the free wheel mechanism See 2007 TM, page 21</p> <p>Replacing the rear bearings See 2004 TM, page 22</p> <p>Replacing a spoke See 2004 TM, page 25</p> <p>Replacing the front rim See 2009 TM, page 38</p> <p>Replacing the rear rim See 2009 TM, page 39</p> |
| <p>Refer to the website for quick and convenient access to information: <a href="http://www.tech-mavic.com">www.tech-mavic.com</a></p>   |                       |   |