

# CROSSMAX SLR 650b (27.5) Center-Lock



**Use:** use only on a Cross-country or Cross-mountain MTB fitted with disc brakes.  
Any other use (such as on a tandem, road bike, cyclo-cross bike, free-ride or downhill bike...) is highly inadvisable, is the sole responsibility of the user and voids the Mavic warranty.

Recommended maximum weight of the cyclist and equipment: 100 kg.

## WHEEL WEIGHT WITHOUT QUICK-RELEASE SKEWER

Front: 710 g  
Rear: 830 g

## WHEEL REFERENCES

Front: 356 032 10  
Rear: 356 033 13  
Pair: 356 034 14

RIMS	SALES REFERENCES	Front: 366 925 10 Rear: 366 926 13
	<b>Ø VALVE HOLE</b> Ø: 6.5 mm	<b>RECOMMENDED TYRE WIDTH</b> Dimensions: ETRTO 584x19C Recommended clincher width: 1.5" to 2.3"
	<b>When replacing the front rim:</b> <ol style="list-style-type: none"> <li>With the valve hole near you, the raised indicator bump must be to the right of the valve hole.</li> <li>The spoke in the first hole to the right of the valve hole is a non-braking spoke and should be inserted in the disc side.</li> </ol> <b>When replacing the rear rim:</b> <ol style="list-style-type: none"> <li>With the valve hole near you, the two raised indicator bumps must be to the right of the valve hole.</li> <li>The spoke in the first hole to the right of the valve hole should be introduced into the drive side in a hole marked on the hub.</li> </ol>	

HUBS	MAINTENANCE: Clean with a dry cloth or soapy water if necessary. Do not use a high-pressure washer.

WHEEL BUILDING	REFERENCES AND LENGTHS:	Front: 366 749 01, length 274 mm (per 10+1 decorated, integrated nipples) Non-drive side: 366 750 01, length 281.5 mm (per 10 + 1 decorated, integrated nipples) Drive side: 366 751 01, length 251.5 mm, (per 10+1 decorated, integrated nipples)
<b>FEATURES:</b> Black, bladed, straight pull Zircal spokes with integrated aluminum Fore nipples	<b>LACING PATTERN:</b> Front: 2-cross lacing on both sides Rear: Isopulse	<b>TENSION:</b> Front: 105 to 115 kg Rear drive side: 105 to 115 kg

ACCESSORIES	WHEELS SUPPLIED WITH:	MAINTENANCE
<ul style="list-style-type: none"> <li>• BX 601 rear quick-release M40141</li> <li>• Mavic wheel bags 857 144 01</li> <li>• 2 Removable round UST valves 129 838 01</li> <li>• Front Adapters 15=&gt;9 mm 996 941 01</li> <li>• Rear Adapter 12=&gt;9.5 mm 308 731 01</li> <li>• Rear Adapters 12x142 mm 308 593 01</li> <li>• Multifunction adjustment wrench 325 423 01</li> <li>• User manual</li> <li>• Sheet of Mavic stickers</li> </ul>		Specific tool: <ul style="list-style-type: none"> <li>• Front bearing: M40119 &amp; M40218</li> <li>• Rear bearing: M40119</li> <li>• Spoke wrench: 996 079 01</li> </ul>
		Refer to the website for quick and convenient access to maintenance information (replacement of an axle, bearings, free wheel, spokes, and rims) <a href="http://www.tech-mavic.com">www.tech-mavic.com</a>