



## REFERENZEN RÄDER

328484 CROSSMAX ST 013 DclREAR12/9

328478 CROSSMAX ST 013 D6lREAR12/9



## RIMS



&NBSP;:

35114013 REAR CROSSMAX ST RIM

## SPOKES

30864401 10 SPOKES M7/7 BLK OPP.DRV CROSSMAX ST 12 269mm  
30864301 11 SPOKES M7/7 BLK DRV CROSSMAX ST 12 239mm

## HUB SHELLS

35126001 ITS-4 FREEWHEEL BODY + SEAL 2013 (WITHOUT PAWLS)  
99610601 ITS4 PAWLS KIT  
30871801 ELASTIC RING 56mm diam.  
M40076 HUB BEARINGS 17x30x7 6903 x 2  
30870401 REAR AXLE KIT ITS4 135mm D6T/DCL 2012  
99610701 ITS4 SEAL

## ADAPTERS

30872201 FORK REST ITS-4 135mm REAR AXLE > 2012  
30873101 2 REAR REDUCERS 12/9,5mm 2012 ITS4 HUB

# **MAVIC** Crossmax ST

## GELIEFERT MIT

BX601 Schnellspanner (HR)	
BX601 Schnellspanner (HR)	
UST-Ventil und Zubehör	
UST-Ventil und Zubehör	
15-mm-Adapter (f $\frac{1}{4}$ r VR)	
15-mm-Adapter (f $\frac{1}{4}$ r VR)	
9,5-mm-Reduzierstück (f $\frac{1}{4}$ r HR)	
9,5-mm-Reduzierstück (f $\frac{1}{4}$ r HR)	
12x142-mm-Adapter (f $\frac{1}{4}$ r HR)	
12x142-mm-Adapter (f $\frac{1}{4}$ r HR)	
Disc-Befestigungsschrauben	
Disc-Befestigungsschrauben	
Speichenmagnet (beim VR)	
Speichenmagnet (beim VR)	
Multifunktions-Einstellschüssel	
Multifunktions-Einstellschüssel	
Bedienungsanleitung	
Bedienungsanleitung	