CROSSMAX ST DISC 10 - 20 mm



WHEEL WEIGHT WITHOUT QUICK-RELEASE SKEWER USE: use only on a Cross-country or Cross Mountain MTB fitted with disc brakes. WHEEL REFERENCES Any other use (such as on a tandem, road bike, cyclo-cross bike, free-ride or Front: 745 g Front: 105 390 10 downhill bike...) is highly inadvisable, is the sole responsibility of the user and 880 g 105 351 13 Rear Rear voids the Mavic warranty. Pair: 105 391 14 Recommended maximum weight of the cyclist and equipment: 100 kg SALES REFERENCES Front: 108 472 10 **RIMS** Rear: 108 472 13 Ø VALVE HOLE **RECOMMENDED TIRE WIDTH** \mathbb{R} Ø: 6.5 mm Dimensions: Ø 26' $Length: \geq 32 \ mm$ FTRT0 559 x 19C compatible and Tubeless UST Recommended tire width: 1.5 to 2.3 When replacing the front rim: 1. With the valve hole near you, the raised indicator bump must be to the left of the valve hole. 2. The spoke in the first hole to the right of the valve hole is a non-braking spoke and should be introduced into the disc side. When replacing the rear rim: 1. With the valve hole near you, the two raised indicator bumps must be to the right of the valve hole. 2. The spoke in the first hole to the right of the valve hole should be introduced into the drive side in a marked hole on the hub. MAINTENANCE: Clean with a dry cloth or soapy water if necessary. **HUBS** Do not use a high-pressure washer. 996 941 01 996 885 01 ((())) ((((Q)))) 996 882 01 M40075 324 129 01 100 M40067 995 000 01 323 890 01 M40580 324 303 01 M40576 **REFERENCES AND LENGTHS** 995 401 01, length 261 mm (per 12 + 2 decorated, integrated nipples) Front: Rear drive side: 995 402 01, length 248 mm (per 12, integrated nipples) WHEEL BUILDING Rear non-drive side: 995 403 01, length 263 mm (per 12 + 2 decorated, integrated nipples) LACING PATTERN: FEATURES: TENSION: Black round, straight pull Zicral spokes (with one decorated per wheel) Front disc side: 120 to 140 kg Front: 2-cross lacing on both sides with integrated, self-locking M7 aluminum spoke nipples Rear: Isopulse Rear drive side: 120 to 140 kg **ACCESSORIES** WHEELS SUPPLIED WITH: **MAINTENANCE** • BX 601 rear quick-release M40141 Replacing the front axle and bearings See 2008 TM, page 24 See 2007 TM, page 20 Removable UST valve 995 282 01 Replacing the rear axle Computer magnet M40540 (with front wheel) Maintaining and replacing the free wheel mechanism See 2007 TM, page 21 • M7 spoke wrench M40494 (with rear wheel) Replacing the rear bearings See 2003 TM, page 22 · Anti-ejection plugs 996 065 01 (with rear wheel) Replacing a spoke See 2003 TM, page 24 · Free play bearing adjustment wrench M40123 (with rear wheel) Replacing the front rim See 2007 TM, page 22 See 2006 TM, page 17 · User guide and warranty card Replacing the rear rim Refer to the website for quick and convenient access to information: www.tech-mavic.com