

Use: use only on a Cross-country or Cross-mountain MTB fitted with disc brakes. Any other use (such as on a tandem, road bike, cyclo-cross bike, free-ride or downhill bike...) is highly inadvisable, is the sole responsibility of the user and voids the Mavic warranty

Recommended maximum weight of the cyclist and equipment: 100 kg

WHEEL WEIGHT WITHOUT QUICK-RELEASE SKEWER

Front 760 g 890 g

REFERENCES

Front: 325 516 10 325 517 13 Rear Pair: 325 570 14

RIMS

SALES REFERENCES

Front and Rear: 351 180 15

Same as ST 12

Ø VALVE HOLE

Ø: 6.5 mm $Length: \geq 32 \ mm$



RECOMMENDED TYRE WIDTH

Dimensions: Ø 26"

ETRTO 559 x 19C and Tubeless UST compatible. Recommended clincher width: 1.5" to 2.3"

When replacing the front rim:

- 1. With the valve hole near you, the raised indicator bump must be to the right of the valve hole.
- 2. The spoke in the first hole to the right of the valve hole is a non-braking spoke and should be inserted in the disc side.


When replacing the rear rim:


- 1. With the valve hole near you, the two raised indicator bumps must be to the **right** of the valve hole.
- 2. The spoke in the first hole to the right of the valve hole is a non-traction spoke and should be inserted in the drive side.

HUBS

MAINTENANCE: Clean with a dry cloth or soapy water if necessary.

Do not use a high-pressure washer.





WHEEL BUILDING

REFERENCES AND LENGTHS

Front and rear non-drive side: Rear drive side:

120 341 01, length 267.5 mm (per 12, integrated nipples) 120 342 01, length 265 mm (per 12, integrated nipples)

FEATURES:

Black, flat, straight pull steel spokes with integrated and self-locking M7 aluminum spoke nipples

LACING PATTERN:

Front and rear: 2-cross lacing on both sides

TENSION:

Front: 100 to 120 kg Rear drive side: 115 to 135 kg

ACCESSORIES

WHEELS SUPPLIED WITH:

- BX 301 rear quick-release skewer M40352
- 2 Removable round UST valves 129 838 01
- Rear Adapters 12x142 mm 329 650 01
- Rear Adapters 12=>9.5 mm 308 731 01 Multifunction adjustment wrench 325 423 01
- · User guides

MAINTENANCE

Specific tool:

Front bearing:

108 850 01 & 996 887 01

• Rear bearing: Spoke wrench: M40119 996 079 01

OPTIONS

Front Adapters 9 mm + quick-release skewer: 996 941 01

Refer to the website for quick and convenient access to maintenance information (replacement of an axle, bearings, free wheel, spokes, and rims)

www.tech-mavic.com