CROSSRIDE DISC

USE: Use only on a Cross Mountain or Cross Country MTB fitted with disc brakes. Any other use (such as on a tandem, Cyclo-Cross bike, road bike, free-ride or downhill bike...) is strongly inadvisable, is the sole responsibility of the user and voids the Mavic warranty.

WHEEL WEIGHTS WITHOUT QUICK **RELEASE SKEWER:**

INT. CL 890 g 885 g Front: Rear: 1040 g 1035 g WHEEL REFERENCES INT. STANDARD:

Front: 995 124 10 Rear: 995 125 13 995 126 14 Pair:

WHEEL REFERENCES **CENTER LOCK:**

Front: 995 133 10 Rear: 995 134 13 995 135 14 Pair:

RIMS

SALES REFERENCES:

Front and rear: 995 434 14

WIDTH

19.5

24,8

VALVE HOLE Ø

Ø: 8.5 mm with 6.5 mm valve adapter Length: ≥ 32 mm

RECOMMENDED TIRE WIDTH AND PRESSURE



Dimensions: Ø 26" only


ETRTO 559 x 19 compatible Recommended tire width: 1.5 to 2.3




Recommended tire pressure: . See page 17

HUBS

MAINTENANCE: Clean with a dry cloth or soap and water. Do not use pressurized water.





WHEEL **BUILDING**

REFERENCES AND LENGTHS:

Front and rear: 995 435 01, length 271 mm (per 12, with nipples)

FEATURES:

Black, bladed, stainless steel, straight pull spokes with brass nipples

LACING PATTERN:

Front and rear: crossed 2 on both sides

TENSION:

Front: 90 to 125 kg Rear drive side: 115 to 145 kg

ACCESSORIES

WHEELS SUPPLIED WITH:

MAINTENANCE

- Traditional aluminum front quick release skewer: M40350
- Traditional aluminum rear quick release skewer: M40351
- Rim tape 559x20x0.6
- User guide and warranty card

Replacing the front axle and bearings

Replacing the rear axle

Maintaining and replacing the free wheel mechanism Replacing the rear bearings

Replacing a spoke Replacing the front rim Replacing the rear rim

See page 21 See 2004 TM page 22 See 2004 TM page 25 See 2004 TM page 28 See 2004 TM page 29

See 2004 TM page 19 See 2004 TM page 20

To quickly consult this information in a practical manner, refer to www.tech-mavic.com